

# MAXIMIZE YOUR DISTANCE WITH CALLAWAY OPTIFIT ADJUSTABILITY



## LOFT AND LIE ADJUSTABILITY INSTRUCTIONS:

The hosel consists of two cogs - an upper cog and a lower cog - that rotate independently to provide a total of 8 possible loft and lie combinations.

**LOFT** settings are designated as:

- “-1” Subtracts 1 degree from Stated Loft
- “S” = Stated loft (Loft stamped on Clubhead)
- “+1” Adds 1 degree to Stated Loft
- “+2” Adds 2 degrees to Stated Loft


**LIE** settings are designated as:

- “N” Neutral Setting
- “D” Draw Setting

## ADJUSTING YOUR CLUB:

**STEP 1** Select the desired loft by selecting one of the four choices (S, -1, +1 or +2) and lining it up with the two white “hash” marks on the top and bottom of the hosel assembly.

**\*\*Keep in mind, the loft selection could be located on either the upper or lower cog.**



DRIVER - CURRENT - OPTIFIT 2

FAIRWAY/HYBRID - NEW - OPTIFIT 3


**STEP 2** On the other cog, select Neutral or Draw by choosing “N” for Neutral or “D” for Draw. Position the “N” or “D” so that it sits between the “hash” marks and in line with the chosen Loft Selection. **\*\*Note: The “D” setting creates a more upright lie angle.**



The new OptiFit 3 hosel is not backward compatible with previous versions of the OptiFit hosel. Using shafts with the older hosel could damage the hosel assembly.

[www.callawaygolf.com/optifitinstructions](http://www.callawaygolf.com/optifitinstructions)

To learn more about the adjustability features



-DRIVER - CURRENT - OPTIFIT 2

FAIRWAY/HYBRID - NEW - OPTIFIT 3