


ASSEMBLY INSTRUCTIONS



The Fairfield Arbor



Please read through before starting assembly.

IMPORTANT: CHECK THE INSIDE OF YOUR POSTS FOR ALL MATERIALS.

Check Box for These Contents

In the event of missing or defective parts please call our customer service dept. at 1 800 282 9346 (Mon. to Fri. 8:00 AM to 4:00 PM EST).

1. Rafters (5) 1 1/2" x 4 1/2" x 38" (3.8 x 11.4 x 96.5 cm)- 10838
2. Pergola End Caps (14) - 10700-1
3. Post Caps (4) - 10824
4. Right Posts (2) 4"x4"x 84" 10 x 10 x 213.4 cm) - 10792
5. Left Posts (2) 4"x4"x 84" - 10821
6. Post Trims (4) - 10737-1
7. Carrying Beams (2) 1 1/2" x 4 1/2" x 63 1/2" (3.8 x 11.4 x 161.3 cm)- 10834-1
8. Side Panel Top-Rails (2) 1 1/2" x 1 1/2" x 31 5/8" (3.8 x 3.8 x 80.3 cm)- 10822
9. Side Panel Vertical Spindles (10) 7/8" x 1 1/2" x 10 3/8" (18.1 x 3.8 x 26.4 cm)- 10795
10. Side Panel Middle Rails (2) 1 1/2" x 1 1/2" x 31 5/8" (3.8 x 3.8 x 80.3 cm)- 10823
11. Side Panel Square Lattices (2) 1/2" x 26 1/2" x 47 3/4" (1.3 x 67.3 x 121.3 cm)- 10793
12. Side Panel Horizontal Bottom Rails (2) 1 1/2" x 1 1/2" x 31 5/8" (3.8 x 3.8 x 80.3 cm)- 10794
13. 3" Stainless Steel Screws (for Rafters) (30) - 20007
14. Tube of Vinyl Glue - 20000
15. #8 x 2 1/2" (6.3 cm.) Stainless Steel Screws (for wood posts) (8) - 20009-1

Additional Materials Required

- 4" x 4" x 4' (122 cm) Long Wood Posts (4) (Only for Option 1)
- Concrete Ready Mix


* Purchase separately from your local lumber store

Tools You Will Need

- Hammer - Tape Measure - Level - Stool or Short Ladder - Shovel - Cordless Drill

General Information


- Read Instructions through carefully before beginning assembly.
- When assembling components, place on a non-abrasive surface (i.e. shipping box) to avoid scratching.
- We recommend an area approx 10'x 8' for unobstructed assembling.
- You should not need to use excessive force when assembling components.



STEP ONE

Assemble the Arbor Top

- 1 Lay out the two carrying beams as illustrated with pre-drilled holes facing up.
- 2 Position the five rafters over the respective predrilled holes on the carrying beams as illustrated.
Note: The self-auguring screws will drill through the internal rib. Keep the screw straight to drill through the internal rib.
- 3 Using the 3" screws fasten the five rafters to the carrying beams.
- 4 Apply vinyl glue to the inside of the end cap and install pergola end caps as illustrated.




STEP TWO

Assemble the Side Panels

- 1 Insert the lattice into the bottom rail as shown.
Note: Bottom rail will have 7 holes on one side only.
- 2 Insert the lattice assembly into the middle rail.
Note: Middle rail will have 7 holes on the bottom side and 5 holes on the top.
- 3 Insert the five spindles into the top side of the middle rail. Note: The middle rail will have 5 holes on one side only.
- 4 Slide the top rail over the lattice assembly.

Repeat for other side panel.

Note: When assembling the lattice and spindles into the middle rail you may find there is not enough room for both parts. Evenly adjust the middle rail so the lattice and spindles meet in the middle inside the rail. These parts will fall into place once you move to step 3 and insert the panel into the posts.




STEP THREE

Attach Side Panels to Posts

- 1** Set out one post and complete the side panel by inserting the side panel assembly into the holes on the post. Push rails until the tabs snap into place.
- 2** Repeat for the adjacent post. Note that there is a Left and Right post. They are marked at the top of the post.

Each side panel should have a Left and Right post.


NOTE: if you intend to install a gate or wings from the arch, before you install the arch, insert a 1 x 4 (3 cm x 10 cm) wood board approximately 5 ft. (152.4 cm) up the inside of vinyl cavity. (1 x 4 (3 cm x 10 cm) wood board purchased separately)



STEP FOUR

Attach Trim Caps to Posts

- 3** Slide trim caps into place as illustrated.
- 4** If you purchased the Trim Kit, also slide the second set of trim caps and base moldings at this point.
- 5** Glue and insert post caps on top of posts as illustrated



STEP FIVE


Connect the Pergola Top to the Posts

- 1 Move side panels to their final location and adjust the opening width to 50 in. (127 cm.).

Place the pre-assembled arbor top onto the post as illustrated.


- 2 Fasten the main carrying beams onto the posts using two screws per side as illustrated.

- 3 Fasten the rafters to the posts using two screws per side as illustrated.



Note: To glue the post trims in place:

1. Slide the post trim down.
2. Apply a generous amount of vinyl glue around the post.
3. Slide the post trim back up to desired location and allow a few minutes to cure.



STEP SIX

Install the Arbor into the Ground

You have Two Options to Complete this Step.

(* purchased separately)

OPTION ONE - If Your Arch:

- is going to be installed with fencing or a gate
- is located in a high wind or hurricane area
- is located in ground conditions that are not level

Consider Using:

***4" x 4" x 4' Long Wood Post (4)**

15 2 1/2" Stainless Steel Screws (8)

- Purchase separate from your local lumberyard
- Recommended to be installed in concrete footing

OPTION TWO - If Your Arch:

- is intended to be used as a stand alone garden accent or pathway
- is located on level ground

Consider Using:

***4" EZ Mount Post (Kit of 4)**


- Purchase from Vita, www.wearevita.com
- Instructions are included with the kit

Into Earth with Concrete Footing (Option One)


Arch must be well secured to prevent tipping over from wind load, etc.

- 1 Insert the four 4"x4"x4' pressure treated wood posts into the bottom of the vinyl posts until they bottom out against the horizontal rail. Fasten with two 2 1/2" long screws per post – on the side of the post (centered) approximately 10" from the bottom. Note that there are no pre-drilled holes.
- 2 Move the arbor to it's final location (you will need a helper).
- 3 When you have identified the location of each post, mark the positions on the ground and then move the arbor aside.
- 4 Excavate four holes approx 38 in. (96.5cm.) deep. The location and excavation of these four holes is the most critical step and should be completed with care.
- 5 Carefully move the arbor back into position and level both horizontally and vertically.
- 6 Check your measurements to confirm that arbor is secured and placed correctly.
- 7 Backfill the holes with cement.

1




2




(Measurements shown are approximate)

3




6



ASSEMBLY INSTRUCTIONS

Cottage Picket Wings



Please read through before starting assembly.

Check Box for These Contents (1 Box)

In the event of missing or defective parts please call our customer service dept. at **1 800 282 9346** (Mon. to Fri. 8:00 AM to 5:00 PM EST).


1. Posts (2) 4" x 4" x 54" (10 cm x 10 cm x 137 cm) - 10126
2. Top Rails (2) 2" x 3.5" x 44.5" (5 cm x 9 cm x 113 cm) - 10103
3. Bottom Rails (2) 2" x 3.5" x 43.5" (5 cm x 9 cm x 110 cm) - 10104
4. Pickets (4) Length 29.25" (74 cm) - 10105
- Pickets (2) Length 30" (76 cm) - 10107
- Pickets (2) Length 31.5" (80 cm) - 10108
- Pickets (2) Length 32.75" (83 cm) - 10109
- Pickets (2) Length 34.25" (87 cm) - 10110
- Pickets (2) Length 36.25" (92 cm) - 10111
- Pickets (2) Length 38.5" (97 cm) - 10112
- Pickets (2) Length 41" (104 cm) - 10113
5. External Post Caps (2) 4" x 4" (10 cm x 10 cm) - 10735-1
6. Post Trim Caps (2) 4" x 4" (10 cm x 10 cm) - 10737-1
7. Base Moldings (2) 5" x 5" (13 cm x 13 cm) - BM20022
8. Rail Mount Brackets (8) 2" x 3.5" (5 cm x 9 cm) - 10045
- Hardware Kit (Includes):**
9. 5/8" (16 mm) Self-tapping stainless Screws (24) - 20016
10. 3" (76 mm) Stainless Steel Screws (8) - 20007
11. Rail end spacers (2) 2" x 3.5" x .5" (5 cm x 9 cm x 13 mm) - 10217
12. Tube of vinyl weld glue (1) - 20000

Tools You Will Need

- Cordless Drill with #2 Phillips bit
- Tape measure
- Pencil
- Level
- Shovel
- Two bags of pre-mix concrete (optional)

General Information

- **Read Instructions through carefully before beginning assembly.**
- When handling components, place on a non-abrasive surface (i.e. shipping box) to avoid scratching.
- We recommend an area approx 5' x 5' (1.5 m x 1.5 m) for unobstructed handling.



Not to Scale

V3 / Sep 26, 2025

Cottage Picket Wings Installation

STEP ONE

A

Lay out one of the posts (part 1). Measure 8" (20.3 cm) from one end of the post and put a mark. Center the rail mount bracket (part 8) on the post, with the open end at the 8" mark. Using two screws 5/8" (16 mm), fasten the bracket to the post as illustrated. Repeat this for the second post. **Note:** All screws are self-tapping and require no pre-drilling.

B



Take one of the posts and measure 29" (73.7 cm) from the same end of the post as in step 1. Put a mark on the post at this distance.

Slip one of the base moldings (part 7) onto the opposite end of the post as illustrated. Slide it up the post until the top edge of the molding is at the 29" (73.7 cm) mark.

C

Center another rail mount bracket on the base molding, keeping the open end of it tight against the raised lip of the base molding trim. Fasten the bracket in place using two 3" (76 mm) screws. Repeat steps A through C for the other post.

Note: The distance between the two brackets should measure approximately 18 3/4" (47.6 cm) when finished.



STEP TWO

A

Insert the bottom rail (part 3) into the bracket on the base molding. Make sure the holes in the rail are facing towards the second bracket on the post. Using one screw 5/8"(16mm), secure the rail in place through the side wall of the bracket as illustrated. Repeat this for the opposite side wall.

B

Insert the top rail (part 2) into the second bracket, making sure the larger sized holes in the rail are facing towards the bottom rail. Secure the rail as described in the previous step. **Note:** The holes in the rail are approx. 1/8" (3 mm) larger on one side to allow for proper alignment of the pickets when mounting. Repeat steps A and B for the remaining post and rails.

C


Break open one bundle of pickets (part 4). Start with the 41" (104 cm) picket at the furthest end of the rails, and insert each one in descending order, ending with two 29 1/4" (74 cm) pickets at the post. Make sure the tabs on the end of the pickets "snap" into the bottom rail. Open the second bundle of pickets and repeat for the opposite wing panel.

A



Bottom Rail is only routed on the one side

B

Top rail is routed on both sides: The larger opening faces the bottom rail.



C



STEP THREE

A


Determine which side of your arbor the wings will be attached to. Fasten a rail mount bracket to the outside of the arbor base molding in the same manner as described in Step 1 (c). **Note:** If your arbor does not have a base mold, install bracket directly on arbor (B). You will need to use 1/2" (13 mm) filler (A) as bottom rail is shorter to allow for base mold.

B

Using two 5/8" (16 mm) screws, fasten a second bracket to the outside of the arbor post as illustrated. The distance between the brackets on the arbor post must equal the distance measured between the brackets on the wing post. Repeat steps A and B for the arbor side panel.

C

Using the distances shown, mark out each hole location on both sides of the arbor. Dig out two 16" (41 cm) deep holes.



STEP FOUR

A

Lower the wing post into the hole, while slipping each rail end into the corresponding bracket on the arbor post. Check the top rail for level, and adjust the depth of the hole if needed. Secure the rail ends to the brackets as described in Step 2 (a), and fill in the hole (for added stability, use pre-mix concrete). Repeat this step for the opposite wing panel. **Note:** The bottom of the wing post base molding should be at ground level when finished.

B



Apply a generous amount of vinyl glue around the post. **Note:** The vinyl glue should be applied below the top of the picket cap level as shown. Slip one trim cap (part 6) over the end of each post. Slide each cap down until the top edge is level with the top of the first picket.

C



Apply a bead of vinyl glue to the underside of each post cap (part 5). To ensure proper attachment to the post, apply the glue to all internal "contact" points of the cap. Place the caps onto the end of each post and push down firmly until the end of the post "bottoms out" on the inside of the cap. Allow a few minutes for the glue to cure. Wipe away excess glue immediately with a damp cloth.

Vinyl glue is to be applied below the picket level.

B



C




vita



CLASSIC 60" GATE PORTAIL CLASSIQUE 60" PUERTA CLASSIC 60"

VA84225

CLASSIC
CLASSIQUE
CLÁSICO



REQUIRED TOOLS AND MATERIALS (NOT INCLUDED)
OUTILS ET MATÉRIAUX REQUIS (NON INCLUS)
HERRAMIENTAS Y MATERIALES REQUERIDOS (NO INCLUIDOS)



PHILLIPS #2



[WEAREVITA.COM](https://www.wearevita.com)

Click - Cliquer - Hacer Clic
"Chat"



[WEAREVITA.COM/SUPPORT](https://www.wearevita.com/support)




HELLO@WEAREVITA.COM




1-800-282-9346



@VITAHOMEANDGARDEN



PARTS LIST
LISTE DES PIÈCES
LISTADO DE PIEZAS



12

x2



1

x1



2

x1



3

x1



4

x1



5

x1



6

x2



7

x2



8

x2




9

x2



10

x12




13

x1



11


x38



14

x1

2




Item No.	Part Number	Description	Dimensions	Qty.
1	10361	Left Post	2" x 3 1/2" x 60 1/2" (5.1cm x 8.9cm x 153.6cm)	1
2	10363	Top Rail (Wood reinforced)	1 1/2" x 3 1/2" x 48 1/4" (3.8cm x 8.9cm x 122.5cm)	1
3	10360	Middle Rail	1 1/2" x 3 1/2" x 48 1/4" (3.8cm x 8.9cm x 122.5cm)	1
4	10359	Bottom Rail	48 1/4" x 3 1/2" x 1 1/2" (122.5cm x 8.9cm x 3.8cm)	1
5	10362	Right Post	2" x 3 1/2" x 60 1/2" (5.1cm x 8.9cm x 153.6cm)	1
6	10355	Vertical Spindle A	7/8" x 3" x 56" (2.2cm x 7.6cm x 142.2cm)	2
7	10356	Vertical Spindle B	7/8" x 3" x 53 3/4" (2.2cm x 7.6cm x 136.5cm)	2
8	10357	Vertical Spindle C	7/8" x 3" x 52 1/2" (2.2cm x 7.6cm x 133.3cm)	2
9	10358	Vertical Spindle D	7/8" x 3" x 51 3/4" (2.2cm x 7.6cm x 131.4cm)	2
10	20016	Short Screw	#8 x 5/8" (1.6cm)	12
11	20126	Long Screw	#10 x 3/4" (1.9cm)	38
12	20083	Hinge	2 3/4" x 4 1/4" (6.8cm x 10.6cm)	2
13	20084	Latch	3 3/4" x 3 5/8" (9.6cm x 9.1cm)	1
14	20085	Catch	9 3/8" x 1 5/8" (23.7cm x 4.1cm)	1

PRODUCT DIMENSIONS

DIMENSIONS DU PRODUIT

DIMENSIONES DEL PRODUCTO



IMPORTANT NOTE! BEFORE YOU BEGIN ASSEMBLING THE GATE

THIS GATE IS COMPATIBLE WITH THE NANTUCKET DELUXE ARBOR (VA84240) AND FAIRFIELD DELUXE ARBOR (VA84242).

IF YOU HAVE THE FAIRFIELD ARBOR (VA84226) OR NANTUCKET LEGACY ARBOR (VA84250), PLEASE FOLLOW THESE ADDITIONAL MODIFIED INSTALLATION STEPS:

- 1. PURCHASE TWO WOOD BOARDS: 1" X 4" X 60" (2.5CM X 10.1CM X 152.4CM)**
- 2. LAY ARBOR POST ON THE GROUND AND INSERT BOARDS INTO INNER POSTS TO SUPPORT HINGE INSTALLATION (SEE IMAGE BELOW)**

NOTE IMPORTANTE ! AVANT DE COMMENCER L'ASSEMBLAGE DE LA BARRIÈRE

CETTE GRILLE EST COMPATIBLE AVEC LA TONNELLE NANTUCKET DELUXE (VA84240) ET LA TONNELLE FAIRFIELD DELUXE (VA84242).

SI VOUS AVEZ LA TONNELLE FAIRFIELD (VA84226) OU LA TONNELLE NANTUCKET LEGACY (VA84250), VEUILLEZ SUIVRE CES ÉTAPES D'INSTALLATION MODIFIÉES SUPPLÉMENTAIRES:


- 1. ACHETEZ DEUX PLANCHES DE BOIS : 1" X 4" X 60" (2,5CM X 10,1CM X 152,4CM)**
- 2. POSEZ LE POTEAU DE LA TONNELLE SUR LE SOL ET INSÉREZ LES PLANCHES DANS LES POTEAUX INTÉRIEURS POUR SOUTENIR L'INSTALLATION DE LA CHARNIÈRE (VOIR L'IMAGE CI-DESSOUS). L'INSTALLATION DES CHARNIÈRES (VOIR L'IMAGE CI-DESSOUS)**

NOTA IMPORTANTE: ANTES DE EMPEZAR A MONTAR LA PUERTA



ESTA PUERTA ES COMPATIBLE CON EL CENADOR NANTUCKET DELUXE (VA84240) Y EL CENADOR FAIRFIELD DELUXE (VA84242).

SI TIENE EL CENADOR FAIRFIELD (VA84226) O EL CENADOR NANTUCKET LEGACY (VA84250), SIGA ESTOS PASOS ADICIONALES DE INSTALACIÓN MODIFICADA:


- 1. COMPRE DOS TABLAS DE MADERA: 1" X 4" X 60" (2,5CM X 10,1CM X 152,4CM)**
 - 2. COLOQUE EL POSTE DEL CENADOR EN EL SUELO E INSERTE LAS TABLAS EN LOS POSTES INTERIORES PARA SUJETAR LA BISAGRA**
- INSTALACIÓN DE LA BISAGRA (VÉASE LA IMAGEN SIGUIENTE)**




PREPARE FRAME OF THE GATE
CONSTRUIRE LE CADRE
CONSTRUIR EL MARCO





IA




IB



2 INSTALL VERTICAL SPINDLES AND HINGES INSTALLER DES BROCHES VERTICALES ET DES CHARNIÈRES INSTALAR HUSILLOS VERTICALES Y BISAGRAS






2A



ENSURE PLACEMENT OF VERTICAL SPINDLES, ONCE INSTALLED THEY CANNOT BE REMOVED
S'ASSURER DE L'EMPLACEMENT DES BROCHES VERTICALES ; UNE FOIS INSTALLÉES, ELLES NE PEUVENT PLUS ÊTRE RETIRÉES
ASEGURAR LA COLOCACIÓN DE LOS HUSILLOS VERTICALES, UNA VEZ INSTALADOS NO SE PUEDEN QUITAR



2B




3






INSTALL LATCH AND BACK OF HINGE
 INSTALLER LE VERROU ET L'ARRIÈRE DE LA CHARNIÈRE
 INSTALAR EL PESTILLO Y LA PARTE TRASERA DE LA BISAGRA



⑩x10



⑫x1




4

USE HINGE TO SECURE GATE ON THE ARBOR
 UTILISER LA HINGE POUR FIXER LE PORTAIL SUR L'ARBRE
 UTILICE HINEGE PARA ASEGURAR LA PUERTA EN EL CENADOR




10x14

4A






GATE AND ARBOR POST CAN BE ADJUSTED USING THESE TWO NUTS
 LE PORTILLON ET LE MONTANT DE L'ARBRE PEUVENT ÊTRE RÉGLÉS À L'AIDE DE CES DEUX ÉCROUS
 LA PUERTA Y EL POSTE DEL CENADOR SE PUEDEN AJUSTAR USANDO ESTAS DOS TUERCAS



LEAVE SOME CLEARANCE
 LAISSER UN ESPACE LIBRE
 DEJAR UN POCO DE ESPACIO LIBRE

4B




PHILLIPS #2



5

INSTALL CATCH ON THE ARBOR POST
 INSTALLER LE LOQUET SUR LE POTEAU DE L'ARBRE
 INSTALE EL RETÉN EN EL POSTE DEL CENADOR





⑬x1



⑩x6

5A



5B

